

Pro**Meister**


User Guide



How to Use



Hold the handle, clip the groove on the front ditch and rotate the tool.



Remove/Install the spring washer smoothly.

RVNR-01